

Frame Protocol of FrSky Telemetry Hub System (V2.0)

1. Frame Format

Header	DataID1	DATA1		Header	DataID2	DATA2		Tail
0x5E		Low	High	0x5E		Low	High	0x5E

The frame starts with 0x5E and ends with 0x5E, with byte-stuffing and data for different sensors separated by 0x5E.

Note: DataID is a sign to identify the data following:

1. DATA Send Form is in Little Endian, except for latitude, longitude, Voltage (Lipo Voltage Sensor), date and time.

Latitude & longitude are separated by "." into 2 bytes

Date is separated in date month and year (DD/MM/YY)

Time is separated in hour minute and second (HH/MM/SS)

2. Byte stuffing method:

2.1 Output:

Byte in frame has value 0x5E is changed into 2 bytes: 0x5D 0x3E

Byte in frame has value 0x5D is changed into 2 bytes: 0x5D 0x3D

2.2 Input:

When byte 0x5D is received, discard this byte, and the next byte is XORed with 0x60.

2. Frame Send

Different data is sent in different time intervals. There are 3 types of frame: FRAME1 is sent per 200ms, FRAME2 is sent per 1s, and FRAME3 is sent per 5s.

Frame1

① Three-axis Acceleration Values, Altitude (variometer-0.01m), Temperature1, Temperature2, Voltage, Current & Voltage (Ampere Sensor), ② RPM

e.g: 5e 24 00 04 5e 25 80 ff 5e 26 e0 fe 5e 10 3c 00 5e 21 3c 00 5e 02 ef ff 5e 05 e9 ff 5e 06 18 34 5e 28 02 00 5e 3a 0a 00 5e 3b 05 00 5e 03 63 00 5e

Note: the first 4 bit of the voltage data refers to battery cell number, while the last 12 bit refers to the voltage value. 0-2100 corresponding to 0-4.2V.

e.g:

.....0x5E 0x06 0x18 0x34 0x5E.....

0x06 refers to the voltage DataID

0x18 0x34

0001 1000 0011 0100

0001(1) means the first cell of pack, the last 12bit 0x834 (2100) means the value is 4.2V

- ① Real RPM value should be the RPM value in Frame1*60
- ② Real three-axis acceleration values should be the three-axis acceleration values in Frame1/1000
- ③ Real current value should be in Frame1/10

Frame2

Course, Latitude, Longitude, Speed, Altitude (GPS), Fuel Level

e.g: 5e 14 2c 00 5e 1c 03 00 5e 13 38 0c 5e 1b c9 06 5e 23 4e 00 5e 12 ef 2e 5e 1a 98 26 5e 22 45 00 5e 11 02 00 5e 19 93 00 5e 01 18 00 5e 09 05 00 5e 04 64 00 5e

Frame3

Date, Time

e.g: 5e 15 0f 07 5e 16 0b 00 5e 17 06 12 5e 18 32 00 5e

DATE: 15.07.2011

TIME: 06:18:50

3. DataID Table

DataID Value	Meaning	Unit	* Form	Resolution and Range (for FrSky Sensors)	Note
0x01	GPS altitude	m	S		Before "."
0x01+8			U		After "."
0x02	Temprature1	°C	S	1°C / -30~250°C	
0x03	RPM	RPM	U	0~60000	
0x04	Fuel Level	%	U	0, 25, 50, 75, 100	
0x05	Temprature2	°C	S	1°C / -30~250	
0x06	Volt	v		0.01v / 0~4.2v	
0x10	Altitude	m	S	0.01m / -500~9000m	Before "."
0x21			U		After "."
0x11	GPS speed	Knots	U		Before "."
0x11+8			U		After "."
0x12	Longitude		dddmm.mmmm		Before "."
0x12+8					After "."
0x1A+8	E/W				
0x13	Latitude		ddmm.mmmm		Before "."
0x13+8			U		After "."
0x1B+8	N/S		U		
0x14	Course	degree	U	0~359.99	Before "."
0x14+8					After "."
0x15	Date/Month				
0x16	Year				
0x17	Hour /Minute				
0x18	Second				
0x24	Acc-x		S	0.016g / -8g ~ +8g	
0x25	Acc-y		S	0.016g / -8g ~ +8g	
0x26	Acc-z		S	0.016g / -8g ~ +8g	
0x3A	* Voltage (Ampere Sensor)	v	U	0.5v / 0~48.0v	Before "."
0x3B					After "."
0x28	Current	A	U	0.1A / 0~100A	

* Form

U refers to unsigned 16 bit data

S refers to signed 16 bit data